

PERKO®

Cat. No. 1312000CHR Ventilators
Cat. No. 1312DP0CHR Ventilators

INSTALLATION INSTRUCTIONS

1. Drill a 3-1/2 inch round hole through the mounting surface at desired location.
2. Thread duct hose into plastic base and pass the hose through hole in mounting surface.
3. Fasten base to mounting surface with four #8 screws or bolts.
4. Insert tabs of chrome ventilator top into matching holes in forward part of base at approximately 45 degree angle. Lower rear end of top to base allowing rear tab to enter matching opening in base. Press down firmly and secure with 8-32 x 3/8 inch stainless steel screw provided.

PERKO, INC