

TV Codes / Códigos de TV / Codes de Téléviseur

Admiral0093, 0463	Matsushita0250
Advent0761	Maxent1755
Akai0812, 1675, 0702, 1935	MB Quart1868
AOC1365, 1589, 2014, 2087, 2479	Megatron0178, 0145
Apex Digital0748, 0765, 1217, 2397	Memorex0463, 0150, 0178, 1670, 1892
Audiovox0451, 0802, 1766, 1769, 1868, 2121	MGA0150, 0178
Aventura0171	Midland0000, 0017, 0051
Broksonic0463, 1935	Mitsubishi1250, 0093, 0150, 0178
Carver0054	Motorola0093
Celebrity0001	MTC0060
Celera0765	NAD0156, 0178
Changhong0765	NEC1797
Citizen0060, 1935	NetTV1755
Coby1634, 2306, 2315, 2344, 2345, 2348	Nexus Electronics2183
Commercial Solutions1447, 0000	Nikko0178
Crosley0001, 0054	Norcent0748, 1365, 1589
Curtis2352, 2466	Olevia1610, 1240, 1331
Curtis Mathes0000, 0054, 0451, 0093, 0060, 0702, 0145, 1661	Optimus0250
Daewoo0451, 1661, 1264	Optoma1348
Dell0145	Optonica0093
Denon0145	Orion0463, 1463
Dumont0017	Panasonic1480, 0250, 1457, 0051, 1291, 2264
Durabrand0463, 0178, 0171	PARK2104, 2194
Dynex1463, 2049, 2184	Penney0000, 0156, 0051, 0060, 0178
Electroband0001	Petters1523
Electrograph1755	Philco0054, 0171, 1394, 1665, 1963
Electrohome0463, 1670	Philips1454, 1866, 0054, 1744, 1856, 2372, 2374
Element1687, 1886, 2183	Pioneer1457
Emerson1864, 0451, 0463, 0178, 0171, 1661, 1394, 1665, 1963	Polaroid1523, 0765, 1276, 1498, 1687, 1766, 1769, 2121
Emprex1422	Portland0451, 1661
Envision1365, 1589, 2014, 2087	Prima0761
ESA0812, 0171, 1963	Prism0051
Funai0001, 0171, 1963	Proscan1447, 0000, 2256
Gateway1755	Proton0178
GE1547, 1447, 0000, 0051, 0451, 0178	Proview1498, 1687
GFM0171, 1665, 1963, 2167	Pulsar0017
Gibraltar0017	Quasar0250, 0051
GoldStar0178	RadioShack0000, 0178
Haier1748, 1749, 2309	RCA1547, 1447, 0000, 0051, 0093, 1661, 1781, 2187, 2247, 2434
Hallmark0178	Realistic0178
Hannsprece1348	Runco0017
Harman/Kardon0054	Sampo1755
Havermy0093	Samsung0812, 0060, 0702, 0178, 1060, 2051
Hello Kitty0451	Sansui0463, 0171, 1670, 1892, 1935
Hisense0748, 1660, 2098, 2355	Sanyo0054, 1142
Hitachi1643, 0145	Sceptre0878, 1217, 1360, 1599, 2506
ilo1394, 1665, 1684	Scotch0178
Infinity0054	Scott0178, 1711
Insighnia1423, 1564, 0463, 0171, 1660, 1710, 1892, 1963, 2049	Sears0000, 0054, 0156, 0178, 0171
Inteq0017	Sharp0818, 0093
JBL0054	Sheng Chia0093
JCB0001	Signature0054
Jensen0761	Sony0810, 0001
JVC0463, 0053, 1253, 1601, 1774, 2264	Soundesign0178
KDS1498, 1687	Soyo1826
KLH0765	Spectroniq1498, 1687
LG1423, 1447, 0017, 0178, 2358, 2424	Squareview0171
LXI0000, 0054, 0156, 0178	Superscan0093
MAG1498, 1687	Supreme0001
Magnavox1454, 1866, 1755, 0054, 0051, 0171, 0802, 1365, 1856, 1963, 2372	SVA0748, 1963
Marantz1454, 0054	Sylvania1864, 0054, 0171, 1394, 1665,

11

.....1886, 1963	Vidtech0178	
Symphonic0171	Viewsonic1755, 0885, 1330, 1365, 1578, 1627, 1640, 1742, 2014, 2087, 2277
Syntax1610, 1240, 1331	Viore1684, 2104, 2352
Tandy0093	Vizio1758, 0885
Technics0250, 0051	Wards0001, 0000, 0054, 0017, 0156, 0051, 0060, 0178
Techwood0051	Waycon0156
Teknika0054, 0150, 0060	Westinghouse1712, 0451, 0885, 1217
Telefunken0702	White Westinghouse0463, 1661
TMK0178	Wyse1365
TNCi0017	Zenith0001, 1423, 0000, 0017, 0463
Toshiba15240156, 0060, 1291, 1935, 2006	Victor0053
TVS0463	Vidikron0054
Victor0053		

VCR / Magnétoscope

Accurian0001	Memorex0035, 0162, 0037, 0048, 0039, 0001, 0046
Admiral0048	MGA0043
Adventura0001	Minolta0042
Aiko0278	Mitsubishi0067, 0043
Aiwa0037, 0001	Motorola0035, 0048
Allegro0039	MTC0001
America Action0278	Multitech0001
American High0035	NEC0067, 0038
Audiovox0037, 0278	Nikko0037
Calix0037	Olympus0035
Canon0035	Optimus0162, 0037, 0048
Carver0081	Panasonic0035, 0162
CCE0278	Penney0035, 0037, 0042, 0038
Citizen0037, 0278	Pentax0042
Craig0037	Philco0035
Crosley0081, 0001	Philips0739, 0035, 0081
Curtis Mathes2000, 0035, 0162, 0278	Pilot0037
Daewoo0045, 0278	Pioneer0067
Denon0042	Polk Audio0081
DirectTV0739	Portland0278
Durabrand0039, 0038	Presidian1593
Dynatech0001	Proscan2000
Electrohome0037, 0043	Pulsar0039
Electrohome0037	Quarter0046
Emerex0032	Quartz0046
Emerson0037, 0001, 0043, 0278, 1593	Quasar0035, 0162
Fuji0035, 0033	RadioShack0001
Funai0001, 1593	Radix0037
Garrard0001	Randex0037
GE2000, 0035	RCA2000, 0035, 0042
GFM1593	Realistic0035, 0037, 0048, 0001, 0046
GoldStar0037, 0038	Runco0039
Gradiente0001	Samsung0045
Harley Davidson0001	Sanky0048, 0039
Harman/Kardon0081, 0038	Sansui0001, 0067
Headquarter0046	Sanyo0046
Hitachi0001, 0042	Scott0045, 0043
Hughes Network Systems0042	Sears0035, 0037, 0001, 0042, 0046
Humax0739	Sharp0048
Instant Replay0035	Signature0035
JVC0067	Sony0032, 0035, 0033, 0001
KEC0037, 0278	STS0042
Kenwood0067, 0038	Sylvania0035, 0081, 0001, 0043, 1593
Kodak0035, 0037	Symphonic0001, 1593
Lloyd's0001	Tashiko0037
LXI0037	Teac0001
Magnavox0035, 0039, 0081, 0001, 1593	Technics0035, 0162
Marantz0035, 0081	Teknika0035, 0037, 0001
Marta0037	Thomas0001
Matsushita0035, 0162	Tivo0739
MEI0035		

12

Toshiba.....	0045, 0043	Villain.....	0001
Totevision.....	0037	Wards.....	2000, 0035, 0048, 0039, 0081,
Vector.....	0045	0033,0045, 0001, 0042, 0038, 0046
Vector Research.....	0038	XR-1000.....	0035, 0001
Video Concepts.....	0045	Yamaha.....	0038
Videomagic.....	0037	Zenith.....	0037, 0039, 0033, 0001

DVD

Accurian.....	0675	Microsoft.....	0000
Akai.....	0695	Mitsubishi.....	1521, 0521
Allegro.....	0869	NAD.....	0741
Apex Digital.....	0672, 0830, 1061	Olevia.....	2331
Bel Canto Design.....	1571	Onkyo.....	0503, 0627, 2147
Blue Parade.....	0571	Panasonic.....	0490, 0503, 1641, 1762
Broksonic.....	0695	Philco.....	0675
California Audio Labs.....	0490	Philips.....	0503, 0539, 2056, 2084, 0646, 0675,
Cinea.....	0831	1267, 1354, 1506, 2434
CineVision.....	0869	Pioneer.....	0571, 0142, 0631, 1571, 2442
Citizen.....	0695	Polaroid.....	1061, 1316
Craig.....	0831	Polk Audio.....	0539
CyberHome.....	0816, 1129	Presidian.....	0675
Daewoo.....	0869, 1172	Proceed.....	0672
Denon.....	0490, 2258	Proscan.....	0000
Diamond Vision.....	1316	RCA.....	0000, 0571, 0822, 2213
Disney.....	0675, 1270	Rio.....	0869
DVD2000.....	0521	Rotel.....	0623
Emerson.....	0675	Sampo.....	0752
Funai.....	0675	Samsung.....	0490, 0573, 0199, 0820, 2069,
GE.....	0000, 0815	2369, 2556
GFM.....	0675	Sansui.....	0695
Go Video.....	0744, 0715, 0741, 0869	Sanyo.....	0695, 0873
GoldStar.....	0741, 0869	Schneider.....	0646
Grundig.....	0539	Sharp.....	0630, 0675, 0752, 2250
Harman/Kardon.....	1229	Shinonic.....	0533
Hello Kitty.....	0831	Sonic Blue.....	0869
Hitachi.....	0573, 0664	Sony.....	1633, 1533, 0533, 0864, 0772, 1070,
Hiteker.....	0672	1431, 1516
ilo.....	1348	Sylvania.....	0675
Insignia.....	0675, 2095, 2428, 2596	Symphonic.....	0675
Integra.....	0571, 0627, 2147	Technics.....	0490
JVC.....	0623, 0867, 1164, 1602, 2365	Theta Digital.....	0571
Kenwood.....	0490, 0534	Toshiba.....	0503, 0695, 2006, 2277, 2705
LG.....	0741, 0869, 1602	Urban Concepts.....	0503
Magnavox.....	0503, 0539, 0646, 0675,	Viore.....	2553
.....	1354, 1506	Vizio.....	2563
Marantz.....	0539	Xbox.....	0000
McIntosh.....	1533	Yamaha.....	0490, 0539, 0646, 0497, 0817
Memorex.....	0695, 0831, 1270, 2213	Zenith.....	0503, 0741, 0869

Satellite / Satélite / Satélite

Bell ExpressVu.....	0775	Mitsubishi.....	0749
DirecTV.....	1377, 0392, 0000, 0639, 1142,	Motorola.....	0869, 0856
.....	0749, 1749, 0819, 1076	Next Level.....	0869
Dish Network.....	0775, 1505	Panasonic.....	0701
Dishpro.....	0775, 1505	Philips.....	1142, 0749, 1749, 1076
Echostar.....	0775, 1505	Proscan.....	0392, 0000
Expressvu.....	0775	RadioShack.....	0869
GE.....	0000	RCA.....	0392, 0000, 0143
General Instrument.....	0869	Samsung.....	1377
GOI.....	0775	Sony.....	0639
Hitachi.....	0819	Star Choice.....	0869
HTS.....	0775	Tivo.....	1142
Hughes Network Systems.....	1142, 0749, 1749	Toshiba.....	0749, 1749, 0790
Jerrold.....	0869	Voom.....	0869
JVC.....	0775		

Cable / Cable / Câblodélecteur

Amino.....	1602, 1822	Pace.....	1376, 1877, 1982
Bright House.....	1376, 1877	Panasonic.....	1982
Cable One.....	1376, 1877	Pioneer.....	1877
Cablevision.....	1376, 1877, 1006	RCA.....	1256
Charter.....	1376, 1877, 2187	Rogers.....	1877
Cisco.....	1877, 1982	Scientific Atlanta.....	1877
Comcast.....	1376, 1877, 1982, 2576	Sejin.....	1602
Cox.....	1376, 1877	Shaw.....	1376
Digeo.....	1187, 2187	Sony.....	1006
i3 Micro.....	1602	Suddenlink.....	1376, 1877
Insight.....	1376, 1877	Thomson.....	1256, 1982
Knology.....	1877	Time Warner.....	1376, 1877, 2187
Mediacom.....	1376, 1877	Tivo.....	2576
Motorola.....	1376, 1187, 1982	WideOpenWest.....	1877
Myrio.....	1602, 1822		

Video Accessories / Accesorios de vídeo / Accessoires vidéo

Access HD.....	2185	Insignia.....	1415
ADB.....	2254	KoolConnect.....	1481
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	LG.....	1415
Amino.....	1481, 1615, 2482	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Motorola.....	0858, 2378
AT&T.....	0858	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Cisco.....	2345	Scientific Atlanta.....	0858, 2345
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	SureWest.....	1481
Daewoo.....	2338	Sylvania.....	1563
Daytek.....	2305	Tivax.....	2185
Digital Stream.....	2303	Ventura.....	2454
Dish Network.....	2470	Venturer.....	2454
Echostar.....	2470	Verizon.....	2378
Epson.....	1563	Winegard.....	2454
GE.....	2360, 2450	Zenith.....	1415
Goodmind.....	2450	Zentech.....	2491
Gridlink.....	2348	Zinwell.....	2488

Digital TV Converter Boxes / Convertidores de TV Digital / Boîtes de conversion pour TV numérique

Access HD.....	2185	Insignia.....	1415
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	Sylvania.....	1563
Daewoo.....	2338	Tivax.....	2185
Daytek.....	2305	Ventura.....	2454
Digital Stream.....	2303	Venturer.....	2454
Dish Network.....	2470	Winegard.....	2454
Echostar.....	2470	Zenith.....	1415
GE.....	2360, 2450	Zentech.....	2491
Goodmind.....	2450	Zinwell.....	2488
Gridlink.....	2348		